




www.MLMEBLE.pl

GB D CZ SK RUS LT
assembly instructions / montageanleitung / montážní návod / montážny návod / инструкции по монтажу / surinkimo instrukcija



INSTRUKCJA MONTAŻU



BEST 08
 140 90 41

akcesoria / accessories / zubehör / příslušenství / prislušenstvo / аксессуары / furnitūra :

x 30 KK 8/32	x 4 KT 6,3/50	x 60 GZ 1,4/25	x 4 SG 8/8	x 24 MD	x 2 ZAM	x 4 ZAM	x 4 PA Ø5	x 20 WT 3,5x16	x 6 WT 4x30	x 4 ZPW
x 4 PK H-4	x 8 WE 6,3x13	x 12 BDP	x 3 UT 1.839	x 1 PKZ	x 1 PAL 350	x 1 WS L 350	x 1 LT	x 1 kluczyk / key / schlüssel / kľuč / ключ / raktas	x 1 klej / glue / kleber / lepidlo / lepidlo / klev / kljaj	

do montażu potrzebne są:

are needed for assembly:
sind erforderlich für die montage:
jsou potřebné pro montáž:
sú potrebné pre montáž:
которые необходимы для сборки:
Surinkimui reikės:



UWAGA ! - mebel należy składać w pozycji poziomej
WARNING! - furniture should be submitted in a horizontal position
WARNUNG! - Möbel sollten in einer horizontalen Position vorzulegen
POZOR! - Nábytek by měl být předložen ve vodorovné poloze
POZOR! - Nábytok by mal byť predložený vo vodorovnej polohe
ВНИМАНИЕ! - Мебель должна быть представлена в горизонтальном положении
DĚMESIO! - Baldą surenkame horizontalioje padėtyje

UWAGA ! - w pierwszej kolejności wbijamy akcesoria „KK” i „MD” w blaty oraz boki.
WARNING! - The first accessory sticks "KK" and "MD" in the tops and sides.
WARNUNG! - Die erste Accessoire-Sticks "KK" und "MD" in den Spitzen und an den Seiten.
POZOR! - První příslušenství holí "KK" a "MD" v korunách a boky.
POZOR! - Prvé príslušenstvo palíc "KK" a "MD" v korunách a boky.
ВНИМАНИЕ! - Первый аксессуаров палочки "KK" и "MD" по верхинам и по бокам.
DĚMESIO! - Pirmiausiai furnitūrą KK ir MD įkalame į stalviršį ir šonus.

Nr/No	Szt/Qty
1	1
2	1
3	2
4	1
5	1
6	1
7	1
8	1
9	1
10	2
11	2
12	3
13	2
14	1
15	1

