





























https://www.szynaka.pl/pl/instrukcje_montazu



Nr				pcs	
1	616	360	5	2	1
2	1040	483	4	1	3
3	1884	419	15	1	3
4	1884	419	15	1	3
5	1884	380	15	1	2
6	618	370	15	1	1
7	235	370	15	1	1
8	618	370	15	1	1
9	235	370	15	4	1
10	900	420	18	1	1
11	900	420	18	1	1
12	1878	247	16	1	2
16	1878	612	16	1	2
17	1898	249	2	1	2
18	1898	632	2	1	2



1



T1


3

B1

4






T1

B1



D2

B1



B1

7




B1

B1






6

B1


2





3





4




5









6



7



8



9

