


B1  ϕ 8x28 x12

M1  x12

T1  x12

C4  x1

W2  x4

J23  x8

C2  x...(12)

T15  x1L

T16  x1R

Y1  ϕ 26
KR15 x4

Y5  H2 x4

E1  6,3x13 x8

S8  4x13 x8

T17  x4

F32  x2



1

Y5
H2 x4

W2 x4

B1 ϕ 8x28 x12







E1 6,3x13 x8

M1 x12


T1 x12

T15 x1L




T16 x1R




2




3




4






5







6



7



8



Verstellmöglichkeiten
Instructions for hinge adjustment
Les possibilités de positionnement
Możliwości regulacji

