





















SYSTEM TADEUSZ T11








1/2



											
2	24	2	4	8	30-40	9	8	8	8	6	2
											
										8	8





zmiierz przekatną

